### Application Note AN3004

### Using the Berkeley Nucleonics Signal Generators as external sources for Anritsu VectorStar™ VNAs

#### Purpose

This application note describes how the Berkeley Nucleonics signal generators can be used as external sources for Anritsu's VectorStar<sup>™</sup> VNA product line.

### Introduction

Anritsu VectorStar<sup>™</sup> VNAs use a dedicated GPIB (general purpose interface bus) port to communicate with up to four external sources.

External sources are required to measure multi-port DUTs like mixers.

Berkeley Nucleonics signal generators with option GPIB support all GPIB features, commands and queries required by the VectorStar<sup>™</sup> system. That enables using them as external sources.

### **Prerequisites**

Any Berkeley Nucleonics signal generator fulfilling the following requirements can be used as an external source for VectorStar<sup>™</sup> VNAs:

- Option GPIB
- Firmware 0.4.123 or later

#### Connections

External sources can be connected to the VNA dedicated GPIB port.

For time base synchronization use a BNC cable to connect VNA reference output "10 MHz OUT" and signal generator reference input "REF IN" as shown in figure 1.





Figure 1: Back panel connections between VectorStar<sup>™</sup> VNA and external source



Figure 2: Model 845-20G external source used as LO for mixer characterization

### Signal generator setup

Some configuration must be done before the signal generator can be used as an external source:

• The VectorStar<sup>™</sup> system expects external sources to listen to specific GPIB addresses. The default setting is:

external source 1 at GPIB address 4 external source 2 at GPIB address 5 external source 3 at GPIB address 2 external source 4 at GPIB address 3

Use the Berkeley Nucleonics GUI to set the GPIB address of Berkeley Nucleonics signal generators. This is shown in figure 3.

This setting is stored and remains unchanged upon power up and \*RST. Note that the generator must be turned off and on for the new setting to become active.

Alternatively, the VectorStar<sup>™</sup> VNA can be configured to use different external source addresses. Refer to the VectorStar Operation Manual [1] for details.

 It is recommended that all external sources are locked to the reference of the VectorStar<sup>™</sup> system.

Use the Berkeley Nucleonics GUI to configure the generator for 10 MHz external reference as shown in figure 4. This configuration can be stored as the power up default. See figure 5.

File Upda	Controller Info BNC SIGN Ite available - click here!	AL GENERA	TOR GUI	V 2.102	
ON	TROL CW SWEE	MODULATION REFE	ERENCE TRIGGER	LF OUT	
De	etected Device	es - USB availab	le		
ID	Device Name	Serial Number	IP / VISA ID	Scan Instruments	
1	Panther 9020B	141-215330000-0237 563-039376E10-0342	192.168.1.124 192.168.1.136	Include GPIB	GPIB Address
3	MODEL 855-6	6A2-041420000-0402	192.168.1.139		
4	MODEL 855-6	6A2-041420000-0400	192.168.1.140	Disconnect	GRIP Adman
				192.168.1.124	
				Connect to	
			75		
Re	mote Control twork Configuration	GPIB De	ry Control Devic evice Settings Memory	e Name Device Name Personalization	

Figure 3: GPIB address setup

🕞 SIGNAL GENERATOR GUI 2.102 -	×
File Controller Info	
- SIGNAL GENERATOR GUI V 2.102	
Update available - click here!	
CONTROL CW SWEEP MODULATION REFERENCE TRIGGER LF OUT	
Enable Reference Output   Image: Disabled   Image: Disa	
Connection established to 192.168.1.55 via LAN	Ready

Figure 4: Reference setup

	NAL GENERATOR	GUI 2.102					- 0	×		
File	Controller In	fo								
Upda	<u>BNC</u> S	IGNA ick here!	L GENE	RA	TOR G	UI V 2	2.102			
CONT	ROL CW	SWEEP	MODULATION	REFE	RENCE TRIG	GER LF O	UT			
De	etected [	<b>Devices</b>	- USB ava	ailab	le					
ID	Device Name	e	Serial Number		IP / VISA ID		Scan Instruments			
1	Panther 9020	В	141-215330000	-0237	192.168.1.124		Include GPIE			
3	MODEL 855-0	5	6A2-041420000	-0402	192.168.1.139		Discourse			
4	MODEL 855-6	5	6A2-041420000	-0400	192.168.1.140		Disconnect			
							192.168.1.55			
							Connect to		Device Settings Memory	X
							DEBUG:	of	Memory selection:	Save current settings
Ren <u>N</u> et	note Control twork Configuration	1	GPIB	Memor De	vice Settings Memory	Device Nam Device Persona	Name ization		1 3 4 5 6 7 8	Save factory defaults Load settings Load factory defaults
Conn	nection establish	ed to 192.168.1.	55 via LAN					Ready	[a	

Figure 5: Store reference configuration as power up default

### VNA setup

Anritsu VectorStar<sup>™</sup> VNAs detect connected external sources automatically. Proper detection can be verified under

Application  $\rightarrow$  Rcvr Config  $\rightarrow$  Multiple Source  $\rightarrow$  Ext. Src Control where a

State[Active/Inactive]

button shows up for each detected source.

Then turn the external source to active state to use it.

If an external source is not detected, check the GPIB cable, check the sources GPIB address configuration or power cycle it.

### An example: mixer downconversion loss characterization

This example starts with the setup shown in figures 2 and 6. A mixer is connected to the VNA and an external source: Mixer RF connected to VNA port 1, IF to VNA port 2, LO to the external source.



Figure 6: Mixer characterization setup

Mixer downconversion loss shall be measured at

- a fixed IF of 30 MHz
- an RF range of 1...18 GHz
- a fixed RF input power level of -10 dBm
- a fixed LO level of +7 dBm

An 845-20G is used as an external source generating the 0.97...17.97 GHz swept LO signal.

The setup steps are:

- 1) Configure the Model 845-20G as explained under "Signal Generator Setup".
- 2) Verify the VNA detects it as explained under "VNA Setup".
- 3) Open the mixer measurement configuration dialog (figure 7). On the VNA: Application  $\rightarrow$  Mixer  $\rightarrow$  Mixer Setup (Active Channel)

The dialog opening lets the user enter the setup.

- a) Check the port assignments:
   Mixer RF connects to VNA port 1, IF to port 2 and LO to external source 1.
- b) Configure frequencies and frequency ranges:
   RF frequency mode "swept", range 1...18 GHz
   LO frequency mode "auto"
   IF frequency mode "fixed", at 30 MHz
- c) Define power levels: RF power -10 dBm LO power +7 dBm

When done, the VNA will configure the external source automatically.

G		BNC Berkeley Nucleonics Corp
$\overline{\mathcal{T}}$	フ	

Mixer Setup [Frequency Sweep] (Ch1)	X
Sweep Type:       Freq Sweep (Linear) <ul> <li>Reverse IF and RF</li> <li>Modular-BB:</li> <li>Off</li> <li>Modular-BB:</li> <li>Off</li> <li>IF Port:</li> <li>Port 1</li> <li>IF Port:</li> <li>Port 2</li> </ul> LO Port:       External Src 1	
Port 1 1 GHz to 18 GHz Power -10 dBm Eff. Pwr: -10 dBm Ext Src1	
970 MHz to 17.97 GHz Power 7 dBm X-Axis Display RF 201	
Define Mixer Measurements Set Frequency Done Cancel	

Figure 7: VNA Mixer Setup

4) The receiver port can now be calibrated.

In this example we skip driver power calibration. Instead a minimal trough line calibration is performed.

- a) Replace the mixer RF-IF path with a through line.
- b) Run the through line calibration:

Calibration  $\rightarrow$  Calibrate  $\rightarrow$  Manual Cal.  $\rightarrow$ 

RcvrCal./Normalization  $\rightarrow$  Thru  $\rightarrow$  1-2

c) Connect the mixer again.

In addition, power and match calibration shall be performed to get accurate results.

Refer to the VectorStar Calibration and Measurement Guide [2] for details.

5) Classical S-parameters are not useful in setups with different port frequencies. Instead the trace displayed can be configured to show scalar measurements. In typical mixer measurements the scalar B2/1 (port 2 received power) response is relevant.



The active trace can be configured under: Response  $\rightarrow$  User defined then select Numerator: B2 Denominator: 1 Driver port: Port 1

The resulting plot (figure 8) shows scalar mixer downconversion loss.



Figure 8: Mixer downconversion loss plot



#### **Related documents**

[1] Operation Manual, VectorStar™ MS464xB Series Microwave Vector Network Analyzer, PN: 10410-00317, Revision P, 2018, Anritsu Company <u>https://dl.cdn-anritsu.com/en-us/test-measurement/files/Manuals/Operation-Manual/10410-00317P.pdf</u>

[2] Calibration and Measurement Guide, VectorStar<sup>™</sup> MS464xB Series Microwave Vector Network Analyzer, Revision R, PN: 10410-00318, 2018, Anritsu Company <u>https://dl.cdn-anritsu.com/en-us/test-measurement/files/Manuals/Measurement-Guide/10410-00318R.pdf</u>